

RF MODULATOR

RF-008

RF Modulator with S-Video & RCA Inputs

Use DVD players/VCRs, Video Game Systems, or Camcorders on a TV that does not have Audio/Video inputs. The RF-008 makes it possible to connect these video sources through your RF (Coaxial) input on your TV:

- Stereo RCA Audio Input
- Composite RCA Video Input
- S-Video Input
- RF (Coaxial) Output
- Channel 3 or 4 Output

New!




AUDIO/VIDEO CONTROL CENTER

CVS2020

4-Way Audio/Video S-Video & RCA Switch Box

With 4 inputs and 2 outputs, this passive switch box is ideal for controlling multi-unit audio/video systems. Video connections are via S-Video / Composite and Audio connections via Stereo RCA. Ideal for switching satellite, HiFi, DVD/CD, Video Camera, Game system, VCR and TV.



AUDIO/VIDEO SWITCH BOXES

CVS856

2-Way Stereo Switch Box


Switch between two stereo inputs. Gold plated RCA jacks and a rugged rocker switch.



CVS878

Audio/Video Control Center

View and record between 3 stereo audio/video devices. Parallel output jacks for second monitor and/or stereo audio through your HI-FI system. Gold plated RCA jacks with pushbutton selector switches.



CVS880

3-Way Audio/Video Switch Box

Select up to three inputs. Switches both the stereo audio and video signal inputs to a parallel output. The parallel output is designed for simultaneous viewing and recording. Gold plated RCA jacks and low profile slide switch.



CVS970

3-Way Stereo Switch Box

Switch between three stereo inputs with gold plated RCA jacks and a 3-position rotary switch.



CVS2094 Discontinued

4-Way Selector Switch

4 Input / 2 Output Stereo Audio and RGB Video switch box. Includes remote control and AC/DC power adapter.

New!



Discontinued

AUDIO/VIDEO MIXERS

CVS910

2 Channel Audio Mixer

Can be used in either 2x (stereo + audio) input or 2x (video + mono) input. Gold plated RCA jacks with dual sliding fader switches.



CVS2004

4 Input Mike Mixer

Ideal for applications demanding control in limited spaces. Use as a multiple microphone mixer or sub-mixer. Gives 4 mono channels, all with microphone input sensitivity and a master peak LED indication.



SPEAKER SWITCH BOXES

Rugged rocker switches with push type speaker terminal jacks mounted in a shielded metal box. Individual control of each speaker pair. Impedance constant at 4-8 Ohms, 200W max.

CVS902

2-Way Speaker Switch

Allows hook up of 2 pairs of speakers to two speaker output.



CVS904

4-Way Speaker Switch

Allows hook up of 4 pairs of speakers to two speaker output.

